

1. Introduction

1.1 Identification

Procedure Name

- Technical Group – CIS 216 – Week 8 – File and Share Access Configuration

1.2 KBSUCKS Instructions

Italicization denote items needed to be modified by the student. What is meant by this is that anything that is italicized is required to be filled in with the student's **own words as they document the assignment**. Then you are to *un-italicize* what I have italicized. This includes the Header, Footer, Table of Contents (TOC), the main body, plus anything else. The instructions in 1.2 can be left as is or removed altogether to fit your document.

1.3 Table of Contents

Contents

1.	INTRODUCTION	1
1.1	IDENTIFICATION	1
1.2	KBSUCKS INSTRUCTIONS.....	1
1.3	TABLE OF CONTENTS.....	1
1.4	REVISION LOG	2
1.5	PURPOSE	2
1.6	HOST INFORMATION.....	2
1.7	ARCHITECTURAL INFORMATION	2
2.	WHAT IS THE ASSIGNMENT?.....	2
2.1	SUMMARY OF THE ASSIGNMENT	2
3.	ASSIGNMENT DETAILS	2
3.1	FILE AND SHARE ACCESS CONFIGURATION	3

Technical Group

Documentation Procedures
 CIS 216

Date: March 5, 2020
 Rev. No: 1.0

1.4 Revision Log

<u>Revision</u>	<u>Date</u>	<u>Updated By</u>	<u>Description of Change</u>
1.0	3/5/20	Mitchell Bartch	Document Creation

1.5 Purpose

The purpose of this document is to provide a walkthrough on creating security groups and shared folders on the Windows Server 2016. Assigning permissions will also be discussed.

1.6 Host Information

	Host Architecture
CPU	Intel Core i5-8600K @3.60GHz
Memory Size	16 GB
HD Size	3 TB
NIC	Intel Ethernet Connection 1219-V

1.7 Architectural Information

	Windows Server 2016 (216DC)	Windows 10 Client (216Client)
CPU	Intel Core i5-8600K @3.60GHz	Intel Core i5-8600K @3.60GHz
Memory Size	2 GB	2 GB
HD Size	50 GB	60 GB
NIC	Intel Ethernet Connection 1219-V	Intel Ethernet Connection 1219-V

2. What is the Assignment?

2.1 Summary of the Assignment

The purpose of this assignment is to create a simple to understand and follow document that will detail the steps necessary to create a shared folder between the Windows Server 2016 and the Windows 10 client, create a mapped drive, and discuss shadow copies and NTFS quotas. A user reading this document should be able to recreate the process detailed here.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0


3. Assignment Details

3.1 File and Share Access Configuration

Windows Server 2016 Configuration

We will begin our configuration on the Windows 2016 Server. Start the server and navigate to the C: drive.

In the C: drive create a new folder named "PIAT". This will become our shared drive for the client PC.



Next we will share this folder and modify its share permissions.


On the "PIAT" folder right-click and open Properties.

Click the "Sharing" tab.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0




Under the "Sharing" tab click the "Advanced Sharing..." button.

Technical Group

Documentation Procedures
CIS 216


Date: March 5, 2020
Rev. No: 1.0



Check the box that says, "Share this folder".


Leave the share name as "PIAT".

Click the "Permissions" button.

Technical Group**Documentation Procedures**
CIS 216Date: March 5, 2020
Rev. No: 1.0

On the Permissions window for “PIAT” highlight the group “Everyone” and click the “Remove” button.

We remove the “Everyone” group as it may pose a security risk, next we will add a different group and set some permissions to them.



Click the “Add...” button.


Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0


You will be greeted with a new window that will prompt you to enter an object name to add to the share permissions for the “PIAT” folder.

Under “Enter the object names to select” enter “Authenticated Users” and click the “Check Names” button.



After a moment it should resolve the entered name and an underline will appear below “Authenticated Users”.

An Authenticated User is a user who accesses the system through a logon process.



When we pressed the “Check Names” button what happened was the service checked the “contoso.com” domain for the Special Identity group named “Authenticated Users”.


Click OK.

Back at the “Permissions for PIAT” window Authenticated users should appear under the “Group or user names:” section. Click the Allow checkbox for Change in the Permissions section below.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Click Apply.

Click OK.


Next we will use Active Directory to create a security group and a new user account that we will then add to our share folder later.

Open Active Directory Users and Computers (ADUC). It can be found under Windows Administrative Tools.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



In ADUC expand “contoso.com”.


First, we will create a new Organizational Unit (OU) to store our new group and user account.

Right-click “contoso.com” and navigate to New -> Organizational Unit.


Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Enter the name "CIS 216".



Click OK.


Next we will add a new user account to the CIS 216 OU.

Right-click the new OU and go New -> User.


Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



In the “New Object - User” window we will create a new user account. Enter in the naming information for your user. When you get to the “User logon name:” enter in the name in the following format: First Initial.Last Name as shown in the screenshot below.



The screenshot shows the 'New Object - User' dialog box. The 'Create in:' field is set to 'contoso.com/CIS 216'. The 'First name:' field contains 'Mitch', the 'Initials:' field contains 'L', and the 'Last name:' field contains 'Bartch'. The 'Full name:' field displays 'Mitch L. Bartch'. The 'User logon name:' field contains 'M.Bartch' and the domain dropdown is set to '@contoso.com'. The 'User logon name (pre-Windows 2000):' field contains 'CONTOSO\M.Bartch'. At the bottom, there are buttons for '< Back', 'Next >', and 'Cancel'.


Take note of the user logon name as we will be logging onto our client later on with this account.

Technical Group**Documentation Procedures**
CIS 216Date: March 5, 2020
Rev. No: 1.0

Click Next.

Next enter in a password for the user account. A strong password consisting of at least 8 characters including numbers and special characters is recommended.

Uncheck the box next to “User must change password at next login” and check the middle two boxes.



The password for this user account will now never expire and the user will not be able to change it. As a note having a password never expire may not be the best practice in a professional setting as frequent password changes are recommended.

Click Next.


The last page shows a summary of the options you have chosen. Review these to ensure they are correct.

Click Finish.


Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Under the CIS 216 OU our user should have appeared.




Next we will make a security group in the CIS 216 group.

Right-click CIS 216 and go New -> Group.

Technical Group

Documentation Procedures
CIS 216


Date: March 5, 2020
Rev. No: 1.0



For the group name enter: "CIS - 216 Users".

Leave the "Group scope" and "Group type" options as they are.

Click OK.




Our security group now also appears in the CIS 216 OU.

Technical Group

Documentation Procedures
CIS 216


Date: March 5, 2020
Rev. No: 1.0



Next we must add our user account to our security group.

Double-click the CIS 216 group and navigate to the “Members” tab.

Click the “Add...” button to add a user account.




Enter in the first name of the user account in the field and click the “Check Names” button.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Select Users, Contacts, Computers, Service Accounts, or Groups

Select this object type:
Users, Service Accounts, Groups, or Other objects

Object Types...

From this location:
contoso.com

Locations...


Enter the object names to select (examples):
Mitch

Check Names

Advanced... OK Cancel

The name should resolve to the full user account name.

Click OK.



Select Users, Contacts, Computers, Service Accounts, or Groups

Select this object type:
Users, Service Accounts, Groups, or Other objects

Object Types...

From this location:
contoso.com

Locations...

Enter the object names to select (examples):
Mitch L. Barch (M.Barch@contoso.com)

Check Names


Advanced... OK Cancel

The user account will now appear as a member of the security group.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Now we will add this group to the NTFS permissions of the “PIAT” folder.


Open the properties window of the “PIAT” folder and navigate to the “Security” tab.

Click the “Edit...” button.


Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Click the “Add...” button to add our group to the permissions.




In the text field enter “CIS” and click the “Check Names” button.

Technical Group


Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



The name should get resolved to our security group.

Click OK.




In the permissions window make sure our “CIS - 216 Users” group is highlighted and click the checkmark to allow the Modify permission.

Click OK.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



The “CIS – 216 Users” has now been successfully added to the permissions on the shared folder.

The reason we added the “CIS – 216 Users” group to the permissions for the shared folder is because permissions should always be assigned to security groups as opposed to an individual. If we added individuals to every object they needed permissions to instead of in groups, it would be much more difficult and time consuming to change permissions. Imagine that an individual either leaves the company or their job otherwise changes; you would need to adjust or remove their permissions on each object they had access too. This way we could instead simply remove their account from the respective groups instead of hunting for them on every object they could access.

Next we will map a drive for this shared folder on the Windows 10 client computer.


Windows 10 Client Configuration

Launch the Windows 10 (216Client) machine.

Upon reaching the login screen instead of logging on as the Administrator account select the “Other user” option.

Technical Group**Documentation Procedures**
CIS 216Date: March 5, 2020
Rev. No: 1.0

Here we will enter in the user account we created in Active Directory and log onto the client as that account. Be sure to preempt the logon name with “contoso\” as you would with the Administrator account as we are not logging in locally.



After you have signed in, we will map a network drive to the shared folder using Windows PowerShell.

Launch Windows PowerShell.

We will be using the “Z” drive for our network drive.

The command you will be using to perform this action is as follows:

```
net use z: \\216dc\piat /persistent:Yes
```

Technical Group

Documentation Procedures
CIS 216


Date: March 5, 2020
Rev. No: 1.0

Let's break down this command a bit so you can understand what it does.

"net use" is a command that is used to connect, remove, and configure shared resources.

"z:" specifies that the "Z" drive will be mapped to our shared folder.

"\\216dc\piat" is the full Universal Naming Convention (UNC) of our shared folder. This specifies where our folder is located on the network. This network path can be found by looking in the "Sharing" tab of the "PIAT" folder.




Finally the "/persistent:Yes" option specifies that the mapped drive will remain even when the computer is shut off or restarted. Mapped drives are not persistent by default so if this option is not used once the machine is restarted you would have to add the mapped drive again.


Enter in the "net use z: \\216dc\piat /persistent:Yes" command and hit the "Enter" key.

```
PS C:\Users\M.Bartch> net use z: \\216dc\piat /persistent:Yes
The command completed successfully.
```

Open "This PC" and you should see the "PIAT" folder mapped to the Z: drive.

Technical Group**Documentation Procedures**
CIS 216Date: March 5, 2020
Rev. No: 1.0

To check that it is persistent restart the client machine.



Log back in as the new user account.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0




Upon returning to “This PC” the mapped drive should still appear.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



All the information on how to map the drive using PowerShell were found at:


<https://www.howtogeek.com/118452/how-to-map-network-drives-from-the-command-prompt-in-windows/>

If we check the properties of the Z: drive, we can see that the “CIS – 216 Users” security group is there under the “Security” tab.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Since we are accessing this share folder over the network with the NTFS permission as Modify and the Share permission as Change, our effective permissions should allow us to read, write, execute, and delete folders and files on the mapped drive. Let's test this by writing a file to the drive.


Open the Z: drive.

Right-click and create a new text document.


Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Name the document "Share Test".




Let's see if the document appears on the server.

On 216DC navigate to C: -> PIAT.

Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



The share is successful.

Shadow Copies and Quota

Next we will return to the 216DC server and create a shadow copy of the C: drive.


A shadow copy is a snapshot of a computer volume. This functions as a backup of sorts as you can access previous versions of a file on the volume shadow copies is enabled on. These snapshots can be taken even when the volume is in use.

Go to “This PC” and right-click the C: drive. Click “Properties”.


Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Navigate to the “Shadow Copies” tab.

Technical Group**Documentation Procedures**
CIS 216Date: March 5, 2020
Rev. No: 1.0

Click the “Enable” button to enable creation of shadow copies of the C: drive.


A window will appear saying that a shadow copy of the drive will be created now and that it will use the default schedule and settings.

Click Yes.

Technical Group

Documentation Procedures
CIS 216


Date: March 5, 2020
Rev. No: 1.0



The C: drive will now have a shadow copy of it made.

Back at the “Shadow Copies” tab you can see when the next shadow copy run will be performed.

Click the “Settings...” button.




Click the “Schedule...” button to see how often shadow copies will be made.


Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



Clicking on the drop-down menu reveals that there are 2 times shadow copies will be run, at 7AM and at 7PM every weekday starting now.




Click OK.


Next let's perform a test of what shadow copies can do for us.

Technical Group**Documentation Procedures**
CIS 216Date: March 5, 2020
Rev. No: 1.0

On the Desktop create a new text file.



Name the file “Shadow Copy Test”.




Navigate back to the C: drive Properties window and under the “Shadow Copies” tab click the “Create Now” button to create a new shadow copy.


Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0



After it has run, delete the "Shadow Copy Test" text file.




Technical Group

Documentation Procedures
CIS 216


Date: March 5, 2020
Rev. No: 1.0

Navigate to the “Previous Versions” tab and select the most recent shadow copy.

Click Open



The shadow copy of the C: drive will now open. This is a version of the drive as it was when the shadow copy was created. From this previous version let’s see if we can retrieve the “Shadow Copy Test” file we just deleted. Navigate to Users -> Administrator -> Desktop. You should see the “Shadow Copy Test” file appear.




Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0

Either drag the file or copy and paste it back to the Desktop.



The file has now been recovered from the shadow copy.

Next we will look at the “Quota” tab.

NTFS Quotas are used to set storage limits for users for a particular volume. A user who exceeds this limit can be issued a warning or denied access. The storage limit is used by the size of files that a user creates or owns.

Navigate to the “Quota” tab.

Here we will make some changes.


Click the button to “Enable quota management”.

Next select limit disk space and change the KB option to EB. This changes the disk space limit from 1 kilobyte to 1 exabyte.

Leave the warning level at 1 KB.


Finally check the box next to “Log event when a user exceeds their warning level”

Click OK.

Technical Group**Documentation Procedures**
CIS 216Date: March 5, 2020
Rev. No: 1.0

A warning window will appear saying that the quota system should only be activated on this drive if quotas are expected to be used and that the volume will be now scanned for usage stats.

Click OK.




To find the logs we enabled in the “Quota” tab open Event Viewer.

The logs will appear under Windows Logs -> System.


Technical Group

Documentation Procedures
CIS 216


Date: March 5, 2020
Rev. No: 1.0



Look for the Event ID of 36. This will correspond to our warning for a user exceeding their quota warning level.



Clicking on one of these logs will provide some details.



Technical Group

Documentation Procedures
CIS 216

Date: March 5, 2020
Rev. No: 1.0

This concludes PIAT - File and Share Access Configuration.